

XLAB® *SPACE-SAVER COMPUTER MOUNT*

This product is only compatible with the **TORPEDO SYSTEM 100/400** or **REFILL UPGRADE KIT**.

TOOLS REQUIRED:

- 2.5mm non-ball ended Allen wrench
- Torque wrench with 2.5mm Allen bit



M4x16mm



Figure A

IMPORTANT:

PLEASE COMPLETELY UNDERSTAND ALL USER INSTRUCTIONS AND SAFETY INFORMATION BEFORE USING THIS PRODUCT. AS WITH ANY HIGH TECH PRODUCT YOU WILL NEED TO ROUTINELY CHECK FOR LOOSE HARDWARE, CRACKS OR OTHER DAMAGE AND REPLACE ITEMS AS NECESSARY. DO NOT USE PRODUCT IF ANY OF THESE CONDITIONS EXIST.

INSTALLATION:

- Using the 2.5mm Allen wrench, remove the screw holding Dolphin Tail to the **TORPEDO BOTTLE**. (You will reuse the M4x16mm screw that held the Dolphin Tail to the **TORPEDO**), set Dolphin tail aside.
- Place the M4 screw through the **SPACE-SAVER COMPUTER MOUNT** and attach to the **TORPEDO BOTTLE** in place of the Dolphin Tail.
- Using torque wrench, torque the M4 screw to 10 in lbs. (1.1 Nm)
- Your **SPACE-SAVER COMPUTER MOUNT** should now look like **Figure A**.
- Mount your computer according to your computer's instructions. (On Garmin 1/4 turn mounts criss-cross the o-rings on the bottom of computer mount)

CARE:

It is not necessary to remove the **SPACE-SAVER COMPUTER MOUNT** when cleaning your bottle, but please remove your computer.

WARRANTY

SPACE-SAVER COMPUTER MOUNT - Limited 2 Year