

TOOLS REQUIRED:

- 4mm non-ball ended Allen wrench
- 8mm open ended wrench



IMPORTANT:

PLEASE COMPLETELY UNDERSTAND ALL USER INSTRUCTIONS AND SAFETY INFORMATION BEFORE USING THIS PRODUCT. AS WITH ANY HIGH TECH PRODUCT YOU WILL NEED TO ROUTINELY CHECK FOR LOOSE HARDWARE, CRACKS OR OTHER DAMAGE AND REPLACE ITEMS AS NECESSARY. DO NOT USE PRODUCT IF ANY OF THESE CONDITIONS EXIST.

STEP 1 MINI MOUNT AND CAGE ATTACHMENT

- REMOVING BOTTLE.** Hold Mount and twist bottle clockwise, lift nose and pull bottle forward and out of the cage. **Figure (A)**
- POSITIONING CAGE AND MINI MOUNT.** Ensure the rear screw is in the rear slot of the cage and in the rear slot in the Mini Mount **Figure (B)**. Tighten the screws to 20 in lbs (2.3 Nm) of torque.
- ATTACHING MOUNT.** Lay the Mount onto the aerobars. Position the rear straps as far back on the bars as possible. If any parts of the mount or screws touch the stem, add the Velcro Pads to the mount. Thread straps through buckles and tighten. **Figure (C)**
- FINAL STRAP TIGHTENING.** The non-slip silicone on the straps should be touching the aerobars. Center the Mount and tighten opposite straps. Then go back and re-tighten all straps to ensure all straps are as tight as you can get them. Make sure that the reinforced (double thickness) section of the polyester straps are in the slot on the **TORPEDO MINI MOUNT**. **Figure (D)**



Figure (A)



Figure (B)



Figure (C)



Figure (D)

STEP 2 BOTTLE INSTALL

- EASY INSTALL.** Rotate the bottle clockwise approximately 1/2 inch. Push rearwards, ensuring the rear tab of the cage slides into the rear bottle recess. Next ensure the rear cage screw head clicks into the long recess on the bottom of the bottle. The rear cage tab should now sit against the vertical surface inside the back of the bottle. **Figure (E)**
- STRAW INSTALL.** Determine which hole is best suited for you. Install the plug in the other hole from the inside of the bottle. Start the plug at an angle and push up around the perimeter of plug. Ensure the top of the plug is completely through the hole. The straw is designed to fit tightly in the straw hole to prevent leaking. To best insert the straw, pinch and fold the end of the straw while pushing it into the hole. For the straw to be vertical, tuck the end of the straw behind the groove in the bottom of the bottle. **Figure (F)** After each ride, gradually trim the straw to your optimum length.
- LID INSTALL.** Push the sides of the lid into the hole until the top of the lid is flush with the bottle.

Figure (E)



Figure (F)



STEP 3 COMPUTER INSTALL (OPTIONAL ACCESSORY)

The **TORPEDO SYSTEM 50+** is designed to be used with or without a computer in front of the bottle for optimal visibility and functionality.

Figure (G) & Figure (H)

'With' Figure (G)



'Without' Figure (H)



- Mount the (optional) XLAB **AERO COMPUTER MOUNT** on the nose of the **TORPEDO MINI MOUNT** with the supplied hardware and instructions.
- The front edge of the computer should sit slightly behind the rider's wrist. Slide the mount along the slot on the **TORPEDO MINI MOUNT** to accomplish this placement and tighten completely to 20 in. lbs (2.3 Nm) of torque.

STEP 4 BOTTLE CARE

WASH YOUR TORPEDO BOTTLE, STRAW, PLUG AND LID EVERY TIME YOU USE IT AND BEFORE INITIAL FIRST USE.

Hand Wash

- Not necessary to remove accessories when cleaning by hand.
- Fill bottle with soapy water.
- Use one hand to cover the holes on top of the bottle.
- Shake bottle vigorously.
- Rinse and repeat.

Cleaning Straw

Hand wash straw in lukewarm water only.
Use a long thin brush to clean tube.
Hot water or the dishwasher will damage straw material.

WARRANTY

VEE CAGE – Limited 2 Year
MINI MOUNT ALUM – Limited 2 year
TORPEDO BOTTLE – Limited 2 Year
All Other Parts – Limited 6 Months