

**IMPORTANT:**

PLEASE COMPLETELY UNDERSTAND ALL USER INSTRUCTIONS AND SAFETY INFORMATION BEFORE USING THIS PRODUCT. AS WITH ANY HIGH TECH PRODUCT YOU WILL NEED TO ROUTINELY CHECK FOR LOOSE HARDWARE, CRACKS OR OTHER DAMAGE AND REPLACE ITEMS AS NECESSARY. DO NOT USE PRODUCT IF ANY OF THESE CONDITIONS EXIST.

## TORPEDO SYSTEM 50

**TOOLS REQUIRED:**

- 4mm non-ball ended Allen wrench.
- 8mm open ended wrench.



### STEP 1 MINI MOUNT AND CAGE ATTACHMENT

- 1. REMOVING BOTTLE.** Hold Mount and twist bottle clockwise, lift nose and pull bottle forward and out of the cage. **Figure (A)**



Figure (A)

- 2. POSITIONING CAGE AND MINI MOUNT.** Ensure the rear screw is as at the rear of the cage and in the rear of the slot in the Mount **Figure (B)**. Tighten the screws to 30 in lbs of torque. (3.4 Nm)



Figure (B)

- 3.** Thread a strap up through the Mount with the logo facing outwards. Pass the strap over the aero bar and through the buckle and attach loosely. Rotate so buckle is under the aero bar.



Shows threading of the straps

- 4. ATTACHING MOUNT.** Lay the Mount onto the aerobars. Position the rear straps as far back on the bars as possible. If any parts of the mount or screws touch the stem, then add the Velcro Pads to the mount. Thread straps through buckles and tighten. **Figure (C)**



Figure (C)

- 5. FINAL STRAP TIGHTENING.** The non-slip silicone on the straps should be touching the aerobars. Center the Mount and tighten opposite straps. Then go back and re-tighten all straps to ensure all straps are as tight as you can get them. Make sure that the reinforced (double thickness) section of the polyester straps are in the slot on the **TORPEDO MINI MOUNT.** **Figure (D)**



Figure (D)

### STEP 2 BOTTLE INSTALL

- 1. EASY INSTALL.** Push bottle rearwards, ensuring the rear tab of the cage slides into the rear bottle recess. Next ensure the rear cage screw head clicks into the long recess on the bottom of the bottle. The rear cage tab should now sit against the vertical surface inside the back of the bottle. **Figure (E)**



Figure (E)

- 2. LID INSTALL.** The lid has a tether hole. Put the straw through this hole to avoid losing the lid when refilling.

- 3. STRAW INSTALL.** Determine which hole is best suited for you. Install the plug in the other hole from the inside of the bottle. Start the plug at an angle and push up around the perimeter of plug. Ensure the top of the plug is completely through the hole. The straw is designed to fit tightly in the straw hole to prevent leaking. To best insert the straw, pinch and fold the end of the straw while pushing it into the hole. For the straw to be vertical, tuck the end of the straw behind the groove in the bottom of the bottle. **Figure (F)** After each ride, gradually trim the straw to your optimum length.



Figure (F)

## STEP 3 COMPUTER INSTALL (OPTIONAL)

The **TORPEDO SYSTEM 50** is designed to be used with or without a computer in front of the bottle for optimal visibility and functionality. **Figure (G) & Figure (H)**

'With' Figure (G)



'Without' Figure (H)



1. Mount the (optional) XLAB **AERO COMPUTER MOUNT** on the nose of the **TORPEDO MINI MOUNT** with the supplied hardware and instructions.
2. The front edge of the computer should sit slightly behind the rider's wrist. Slide the mount along the slot on the **TORPEDO MINI MOUNT** to accomplish this placement and tighten completely to 30 in. lbs of torque. (3.4 Nm)

## STEP 4 BOTTLE CARE

**WASH YOUR TORPEDO BOTTLE, STRAW, PLUG AND LID EVERY TIME YOU USE IT AND BEFORE INITIAL FIRST USE.**

### Dishwasher

1. Remove all accessories from the bottle before washing (straw, plug and lids)
2. Wash in top rack only.

### Hand Wash

1. Not necessary to remove accessories when cleaning by hand.
2. Fill bottle with soapy water.
3. Use one hand to cover the holes on top of the bottle.
4. Shake bottle vigorously.
5. Rinse and repeat.

**Cleaning Straw:** Use long thin brush to clean tube.

### WARRANTY

**VEE CAGE** – Limited 2 Year  
**MINI MOUNT ALUM** – Limited 2 Year  
**TORPEDO BOTTLE** – Limited 2 Year  
All Other Parts – Limited 6 Months

## STEALTH POCKET 400: HELPFUL TIP WHEN INSTALLING

When tightening the strap around your top tube, make sure you do not tuck excess strap in between the top tube and bag. Excess strap material underneath the bag will reduce the gripping power of the bag.

**WARRANTY** – Limited 2 Year

## NANOFLATOR INSTRUCTIONS

**IMPORTANT: Please completely understand all user instructions and safety information before using this product.**

### 1. PREPARE INFLATOR

NOTE: Do not activate a CO<sub>2</sub> cartridge until ready to use. Threaded CO<sub>2</sub> cartridges: Thread cartridge into the threaded base of inflator until the cartridge just contacts the puncture pin, then quickly and firmly twist to puncture (activate) the CO<sub>2</sub> cartridge. Inflator is now charged.

### 2. CONNECT TO TIRE VALVE

IMPORTANT: Presta valve **MUST** be opened before inflating tire. Failure to open valve completely may cause injury or damage to inflator. Presta & Schrader valves: Thread the head of the **NANOFLATOR** directly onto the tire valve.

### 3. CONTROLLABLY INFLATE

IMPORTANT: Hold CO<sub>2</sub> cartridge upright for best results. Twist the black knob counter clockwise to release CO<sub>2</sub> into the tire. Do not unthread CO<sub>2</sub> until air has been completely released. CAUTION: CO<sub>2</sub> cartridge must be completely empty before removal from inflator. An activated cartridge removed from an inflator is dangerous! Do not over-inflate tire as injury can result. To remove inflator, unscrew the head from the tire valve.

**WARRANTY** – Limited 2 Year

## CO<sub>2</sub> CARTRIDGES CAUTION

CONTENTS UNDER PRESSURE. DO NOT PUNCTURE OR HEAT ABOVE 120F / 49C. DO NOT INHALE OR DISCHARGE TOWARDS FACE OR BODY. KEEP CARTRIDGE AND DISPENSER OUT THE REACH OF CHILDREN. DO NOT LEAVE IN ENCLOSED VEHICLE AS RUPTURE MAY OCCUR DUE TO OVERHEATING AND MAY CAUSE INJURY.

## DELTA 100

### TOOLS REQUIRED:

4mm Allen wrench.  
8mm open ended wrench.  
Torque Wrench



### MULTI-STRIKE REPAIR HOLDER



### NOTE

The **P-CAGE & MULTI-STRIKE REPAIR HOLDER** come loosely attached to the **DELTA** Mount with 30mm long screws. This **DELTA** has a 3/8" black cylindrical spacer on the bottom screw. The spacers are to ensure that even with long saddles like the fi'zi:k that the water bottle will clear the rear of the saddle. There are also two silver 1/8" spacers beneath the locking nuts, to allow easy access to the nuts with an 8mm wrench. The mount is attached loosely to its backplate with two 15mm screws with Loctite on the threads that will help prevent the screws loosening once installed on the saddle. Do not fully tighten the cage until the last step. This will help with installing the mount to the saddle.

### INSTALLATION INSTRUCTIONS

1. Unscrew the two 15mm screws from the backplate.
2. Hold the Mount up to the back of the saddle rails and position the backplate inside the rails.
3. Insert the two 15mm screws through the Mount into the backplate. Hand-tighten and then check that the cage is in the position you require. Tighten to 30 in.lbs (3.4 Nm) of torque. The Loctite on the threads will harden over 24 hours. You can still remove the screws in the future, but Loctite is a one-time use. You can purchase replacement screws with Loctite on the XLAB web store.
4. Using a 4mm Allen wrench and an 8mm wrench, fully tighten the two 30mm long screws holding the cage to the mount. Tighten to 30 in.lbs (3.4 Nm) of torque.

### WARRANTY

**DELTA** Mount - Limited 2 year

**P-CAGE** - Limited 2 year

**MULTI-STRIKE REPAIR HOLDER** - Limited 2 year