

VERSA COMPUTER MOUNT

Compatibility: VERSA 200, VERSA 500, VERSA SLIM models.

PLEASE COMPLETELY UNDERSTAND ALL USER INSTRUCTIONS AND SAFETY INFORMATION BEFORE USING THIS PRODUCT. AS WITH ANY HIGH TECH PRODUCT YOU WILL NEED TO ROUTINELY CHECK FOR LOOSE HARDWARE, CRACKS OR OTHER DAMAGE AND REPLACE ITEMS AS NECESSARY. DO NOT USE PRODUCT IF ANY OF THESE CONDITIONS EXIST.

HARDWARE



TOOLS REQUIRED

2 mm Hex Wrench 3 mm Hex Wrench Torque Wrench up to 2.8 Nm (25 in lbs)





COMPUTER MOUNT INSTALLATION

TOOLS REQUIRED

3 mm Hex Wrench Torque Wrench up to 2.8 Nm (25 in lbs)

- Place the Torpedo Versa Computer Mount at the front of the Torpedo Versa
 Mount directly underneath. The base of the computer mount should fit snug
 against the front edge of the Versa Mount. Align the two threaded holes
 with the mounting holes on the Versa Mount.
- 2. Find the appropriate mounting screws for your Torpedo Versa Mount. If you have the Carbon mount, use the included M4 x 10 mm Flat Head Screws. If you have the Aluminum mount, use the included M4 x 10 mm Button Head



TORPEDO VERSA CARBON MOUNTS: M4 x 10 mm Flat Head Screws



FOR TORPEDO VERSA ALUMINUM MOUNTS: M4 x 10 mm Button Head Screws

3. Insert each of the screws through one of the two mounting holes on the front of the Torpedo Versa Mount and into the base of the computer mount using the 3 mm Hex Wrench. Hand-tighten each of the screws.

- 4. Tighten each of the two mounting screws to 2.8 Nm (25 in lbs).
- 5. Adjust the computer mount to the appropriate height for you by moving the post up and down.
- 6. Tighten the side screw to lock in place and torque to 2.8 Nm (25 in lbs). The screw must be fully tightened for the computer mount to stay in place.
- 7. Attach the computer and rotate as needed to achieve the preferred angle.





WARNING: Large top bolt already set to factory standards, do not adjust.

FOR GARMIN® MULTISPORT WATCHES & WAHOO® COMPUTERS

Note 1: Torpedo Versa Computer Mount is compatible with Garmin® & Wahoo® bike computers and watches. Optional adapters are available to purchase separately for Polar®, and strap-mounted computers.

Note 2: The Computer Mount's default position will accommodate Garmin® bike computers - no adjustment is necessary.

TOOLS REQUIRED

2 mm Hex Wrench Torque Wrench up to 1.1 Nm (10 in-lbs)



1. Remove the two screws at the top of the computer mount using the 2 mm Hex Wrench.



2. Rotate the holder 90 degrees.



- 3. Reinsert the screws and tighten.
- 4. Torque both screws to 1.1 Nm (10 in-lbs).

WARRANTY
Limited 3 Year.