

USER INSTRUCTIONS AND IMPORTANT SAFETY INFORMATION

IMPORTANT: Please completely understand all user instructions and safety information before using this product.
If the instructions below are not followed, the risk of damaging the seat post is likely.

As with any high-tech product you need to routinely check the **DELTA SONIC ML** for loose hardware, cracks or other damage, replacing items as necessary. Do not use product if any of these conditions are found.

TOOLS REQUIRED

3mm Hex Wrench
4mm Hex Wrench
Torque Wrench up to 35 in Lbs (4.0 Nm)



INSTALLATION INSTRUCTIONS

1. Remove zip ties from **GORILLA** cage.
2. Mount the **GORILLA** cage to the back of the **DELTA SONIC ML** rod using the (2) M4 x 12mm Socket Head screws and M4 Fender Washers.
3. Each M4 x 12mm screw should first go through the M4 Fender Washer and next through the **GORILLA** cage, and finally into the threaded holes in the back of the rod.
4. Tighten screws to 15-20 in lbs (1.7-2.3 Nm) of torque.
5. Insert the rod into the back of the seat post to desired location. The rod will slide back and forth independently from the seat.
6. Place the seat post clamp on top of the seat post with the long side towards the back of the bike. If the clamp overhangs off the seat post, turn it around so the long side is towards the front of the bike.
7. Place the M5 x 12mm screw through the seat post clamp, then through the seat post slot and into the threaded hole in the top of the rod.
8. Access to the screw may be difficult. It may be necessary to remove the seat to properly tighten the **DELTA SONIC ML** rod. Tighten M5 x 12mm screw to 30-35 in lbs (3.4-4.0 Nm) of torque. The Loctite on the threads will harden over 24 hours. You can still remove the screws in the future, but the Loctite is a one-time use. You can purchase replacement screws with Loctite on the XLAB web store.
8. Your **DELTA SONIC ML** should now be installed and look like the image.

To mount the **MULTI-STRIKE REPAIR HOLDER** or **AERO POUCH 300** use the supplied M4x18mm screws included in those kits and refer to the instructions for these products.

MAINTENANCE

Frequently check that all screws are tight. The included screws have non-permanent Loctite and is good for the initial install. If the screws are removed after installation re-apply Loctite to the screw thread or purchase new screws with Loctite on the XLAB web store.

WARRANTY

The **GORILLA** cage comes with a limited lifetime warranty.
The **DELTA SONIC ML** rod comes with a 3 year limited warranty.
See website for more details.

